

FREE FLYTE ELITE

FREE FLYTE MICRO

FREE FLYTE

patent number 5503136

The Free Flyte series of arrow rests has been designed as the ultimate in finger shooting rests. This trio of rests has been performing at a world class level on both target bows and hunting bows for many years.

Mounting

Each of these rests can be mounted to your bow with the bolt supplied or with a cushion plunger. If you choose to use a cushion plunger, the spine point can be removed from both the Standard and Micro Free Flyte. The Elite Free Flyte has an additional quick detach mount that can be mounted to your bow with the two 6x32 screws enclosed.

Adjusting

Adjust your rest horizontally before you begin to adjust the arrow support arm. When the arrow support arm is folded into the bow it should lay flat against the window. The arrow support arm has a slight hook in it to cradle the arrow against the spine point or cushion plunger tip. The arrow support arm can be adjusted in two ways. For major adjustments, loosen the screw in the pivot block. For minor adjustments, use the adjustment screw.

The rest has been assembled with the reversible magnet set to repel the magnet in the pivot block. In this position the rest can be used as a flipper style rest. to change the rest to have the arrow support arm move out of the way upon release, simply remove the orange magnet and reverse ends. In this position the arrow support arm needs to be pulled tight and the arrow placed on the support arm. The weight of the arrow will hold the support arm out until the arrow is released. At the point of release the arrow will bend and move slightly off the rest and the arrow support arm will move in towards the bow before the fletching gets there. Therefore the name *Free Flyte*.

