

# Instruction Manual



## Riser ILF Scream


*Bignami*<sup>®</sup>  
dal 1939

**ATTENTION**

This manual describes how to assemble and use the bow you purchased. To keep it safe and performing use it as here below described and shown in the images.

The manual doesn't replace the training course that will teach you how to properly shoot the bow.

Use the bow always under the lead of a trained person.

**ATTENTION!**

The product is a professional product. Before using it read the following instructions carefully.

1. dry fire is forbidden, this means you never draw the bow open without the arrow cocked and release the string.
2. drawing the bow beyond its limit is forbidden. Drawing it longer than allowed may damage the limbs.
3. do not aim the bow at persons. When the bow is loaded (with a cocked arrow) do not aim it at anybody.
4. Do not leave the bow strung for a long period of time. This may cause limbs deformation or draw weight loss.

5. avoid high temperatures. High temperatures may affect the glue behaviour and therefore the performances or the life length of the bow.

- Bare bow weight: 1360g
- Length of the magnesium alloy riser: 25"
- Draw weights up to: 60#
- Brace height: 17.5-18.5 cm
- Maximum draw weight: 30"

### ASSEMBLY THE BOW

Start mounting the limbs on the riser. See photos 3 and 4.



photo 1



photo 2



photo 3



photo 4



The result of after the completion of the installation of the bow

photo 5

### TILLER/BOW WEIGHT ADJUSTMENT

If you need to adjust the draw weight or the tiller you need to adjust the tiller bolts. First unlock the back fixing screw on each tiller bolt. The tiller bolt can be upwinded 5 turns out from the completely locked position. After each tiller bolt position has been adjusted fix the back locking screw.

**STRINGING THE BOW**

String the bow using a bow stringer in order to avoid damages to the limbs. Make sure the bow stringer is used properly in order to avoid limb twist.



PHOTO 6

PHOTO 7



PHOTO 8



PHOTO 9

**NOTE:**

**NOTE:**

**NOTE:**

**Translations by Bignami Spa.**

**The data in this publication were provided by the manufacturer  
and are subject to change at any time without notice.**

**Bignami Spa is not responsible for inaccuracies and / or  
typographical errors.**



*Bignami*<sup>®</sup>  
dal 1939

**Bignami S.p.A.**  
Via Lahn,1 - 39040 Ora (BZ)  
Tel. 0471 803000  
[www.Bignami.it](http://www.Bignami.it)