

# General Instructions



## UniPress Adapter

*Bignami*<sup>®</sup>  
dal 1939

## UniGram UniPress

The UniPress is an easy to install, easy to use adapter for existing finger style bow presses.

The adapters allow finger style presses to work safely on beyond parallel bows and is approved by Hoyt for work on their bows with UltraFlex limbs.

The product is patent pending, application no. 2165459.



### What is in the box:

2 pcs of adapter, one for each limb end.

This user guide



The adapters are set to the correct length for pressing Hoyt Defiant series bows.



Each adapter consist of:

1. Limb pocket hook with 1a. lever and 1b. lock piece
2. Spacer block with finger screw
3. 2 limb tip hooks
4. Tension rope

#### Quick guide:

The adapters are ready to use for the Hoyt Defiant series of bows. Follow steps 1-5 (6 if needed) to safely press the bow.

#### 1: Take one adapter and place on limb pocket

The adapter should be fully open, it is opened by squeezing the two arms and sliding the locking block to either side.



#### 2: Place the Limb tip adapters on each limb tip.

Ensure that the tip adapters are centered on the limbs.



3: Align the ropes and close the lever until the lock engages.  
Ensure that everything is stable



4: Close lever fully

At this point you are ready to press the bow, ensure that you have a good amount of pre-tension. You should not be able to deflect the ropes without using substantial force.



5: Ensure that no gaps are present.

Before pressing, no gaps should be visible between limb tip adapter and limb.

CAUTION: When pressing a small gap might occur, but should never exceed 1/8" – 3 mm during pressing.



**6: Length adjustment. (If Needed)**

With the lever open, with lock pieces engaged, it is possible to change the adapter length. To change length, follow below steps.

1. Loosen the finger screw on the spacer piece.
2. Ensure the limb pocket and limb tip adapters are in the correct position.
3. Pull the spacer bar firmly towards the limb pocket adapter.
4. While maintaining pressure tighten finger screw.

**7: Ready to press bow:**

Once both adapters are installed, the bow can be pressed in the same manner as other bows with parallel or under parallel limbs.

**Caution:**

The UniPress adapters are used to press a compound bow under high tension. Utmost care must be taken to operate safely. Operator must be schooled on the mechanics of the compound bow before using the adapters.

**Disclaimer:**

UniGram Aps cannot be held accountable for injury, harm or damage to personnel or equipment due to improper use. UniGram Aps will be happy to share information on proper usage to ensure correct and safe pressing.

Product demo video:



**NOTE:**

**NOTE:**

**Translation by Bignami S.p.A.**

**The data in this manual have been provided by the manufacturer and may be subject to change at any time without notice.**

**Bignami SpA is not liable for any inaccuracies and / or possible typographical errors.**



*Bignami*®  
dal 1939

**Bignami Spa**  
Via Lahn,1 - 39040 Ora (BZ)  
Tel. 0471 803000  
[www.Bignami.it](http://www.Bignami.it)